



► PSS u2 PS1 -R

PILZ
THE SPIRIT OF SAFETY

Operating Manual-1006251-EN-01

- PSS u2 in the automation system PSS 4000



This document is the original document.

Where unavoidable, for reasons of readability, the masculine form has been selected when formulating this document. We do assure you that all persons are regarded without discrimination and on an equal basis.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for the user's internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



SD means Secure Digital

1	Introduction	5
1.1	Validity of documentation	5
1.2	Using the documentation	5
1.3	Terminology	5
1.4	Definition of symbols	6
1.5	Third-party manufacturer licence information	6
2	Overview	7
2.1	Module features	7
2.2	Front view	8
3	Safety	9
3.1	Intended use	9
3.2	Application conditions in accordance with EN 50124-1:2017	9
3.3	System requirements (PSS u2 in automation system PSS 4000)	10
3.4	Safety regulations	11
3.4.1	Additional documents that apply	11
3.4.2	Use of qualified personnel	11
3.4.3	Warranty and liability	11
3.4.4	Disposal	11
4	Security	12
4.1	Security (PSS u2 in the automation system PSS 4000)	12
5	Function description	13
5.1	Block diagram	13
5.2	Supply voltage	13
5.2.1	Output power of module supply	14
5.2.2	Current load capacity of periphery supply	15
5.3	Integrated protection mechanisms	16
6	I/O data of the module (PSS u2 in the automation system PSS 4000)	17
6.1	Available I/O data in the I/O mapping	18
6.2	Other I/O data	19
7	Installation	20
7.1	General installation guidelines	20
7.1.1	Dimensions	20
7.2	Insert and remove main voltage supply module	21
7.3	Install backplane	21
7.4	Install protective plate	22
7.5	Insert main supply voltage module next to head module	23
7.6	Install head module plus main voltage supply module	24
7.7	Insert terminal block	25
8	Wiring	26
8.1	General wiring guidelines	26
8.1.1	Connection mechanism for terminal blocks	26

8.2	Terminal configuration.....	27
8.2.1	Connecting the module	27
9	Operation	29
9.1	Display elements and messages	29
10	Technical details	31
11	Supplementary data	34
11.1	Permitted operating height	34
12	Order reference	35
12.1	Product.....	35
12.2	Accessories.....	35

1 Introduction

1.1 Validity of documentation

This documentation is valid for the product PSS u2 PS1 -R from Version HW 1.0, FW 1.03 .

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

1.2 Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

1.3 Terminology

PSS u2 system

System from a PSS u2 head module and PSS u2 electronic modules.

PSS u2 in the automation system PSS 4000

PSS u2 system with control functionality that can be used in the automation system PSS 4000. A PSS u2 system is a 2nd generation device in the automation system PSS 4000.

The configuration is performed in the tool PAS4000.

1.4 Definition of symbols

Information that is particularly important is identified as follows:



DANGER!

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



WARNING!

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



CAUTION!

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



NOTICE

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.



INFORMATION

This gives advice on applications and provides information on special features.

1.5 Third-party manufacturer licence information

This product includes Open Source software with various licenses.

Further information is available in the document "Third-party manufacturer licence information PSS u2 PS1 -R" (document number 1006670) at www.pilz.com.

2 Overview

Module structure:

A module consists of

- ▶ the main voltage supply,
- ▶ a terminal block with cage clamp terminals

The main voltage supply module is attached to the head module along the rail of the head module. The terminal block is plugged into the main voltage supply module and is used to connect the voltage supply.

Details of the terminal blocks that can be used are available under "Intended Use".

2.1 Module features

Use of the product PSS u2 PS1 -R:

Module to supply the PSS u2 system in the automation system PSS 4000

The product has the following features:

- ▶ Infeed for module supply (supplies head modules and subsequent modules)
- ▶ Infeed for periphery supply
- ▶ Monitoring for undervoltage/overvoltage/overload of the periphery supply
- ▶ Monitoring of the module supply
- ▶ Status LED for the module

2.2 Front view




Fig.: Front view PSS u2 PS1 -R

Legend

[1]	Product name
[2]	Order number
[3]	Module status, see Display elements and messages [📖 29]
[4]	2D code product information
[5]	Hardware version
[6]	Serial number
[7]	Module supply
[8]	Periphery supply
[9]	Functional earth

3 Safety

3.1 Intended use

The module may be used for railway applications in the following PSS u2 system (see [Terminology](#)  5):

- ▶ PSS u2 in the automation system PSS 4000 (generation 2)

The module PSS u2 PS1 -R is used to voltage supply for the head module and the modules.

The module PSS u2 PS1 -R may only be used in the PSS u2 system.

Intended use includes making the electrical installation EMC-compliant. The module is intended for use in railway applications. Interference may occur if used in other areas.

The following is deemed improper use in particular:

- ▶ Any component, technical or electrical modification to the module,
- ▶ Use of the module outside the areas described in this operating manual,
- ▶ Any use of the module that is not in accordance with the technical details.
- ▶ Interference voltage on the supply lines

The user must employ additional measures on the voltage supply inputs to ensure compliance with the limit values for the conducted noise emission in accordance with EN 50121-4:2016 + A1:2019. Compliance with the limit values is achieved by connecting a noise suppression filter between the external power supply and the voltage supply inputs if, for example, a type FN2070-3-... mains filter from Schaffner is used, or a noise suppression filter with comparable properties.

The module PSS u2 PS1 -R may be used in conjunction with the following terminal block:

- ▶ 9-pin terminal block

With reference to the standard IEC 61131-2 the values stated in the technical details for ambient temperature are reduced at heights >2000 m operating height above sea level (see [Supplementary data](#)  34).

3.2 Application conditions in accordance with EN 50124-1:2017

- ▶ Rated surge voltage outdoors = 3100 V (section 8.2.2.2)

The main supply voltage module does not meet these requirements. The plant operator must ensure that appropriate protective measures are implemented.

- ▶ Rated surge voltage indoors = 2200 V (section 8.2.2.3)

The main supply voltage module does not meet these requirements. The plant operator must ensure that appropriate protective measures are implemented.

3.3 System requirements (PSS u2 in automation system PSS 4000)



INFORMATION

The module is supported by

► PAS4000, from Version 1.25.0

- We recommend that you always use the latest version (download from www.pilz.com).

3.4 Safety regulations

3.4.1 Additional documents that apply

Please read and take note of the following documents:

- ▶ Installation Manual PSS u2 in the automation system PSS 4000 (1006253)
- ▶ System Description PSS 4000 (1001467)
- ▶ Product Modifications PSS 4000 (1001740)

When using railway applications, please note also:

- ▶ System description Safety architectures for railway applications (1006614)

You will need to be conversant with the information in these documents in order to fully understand this operating manual.

3.4.2 Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, maintained and decommissioned by competent persons.

A competent person is a qualified and knowledgeable person who, because of their training, experience and current professional activity, has the specialist knowledge required. To be able to inspect, assess and operate devices, systems and machines, the person has to be informed of the state of the art and the applicable national, European and international laws, directives and standards.

It is the company's responsibility only to employ personnel who

- ▶ Are familiar with the basic regulations concerning health and safety / accident prevention,
- ▶ Have read and understood the information provided in the section entitled Safety
- ▶ Have a good knowledge of the generic and specialist standards applicable to the specific application.

3.4.3 Warranty and liability

All claims to warranty and liability will be rendered invalid if

- ▶ The product was used contrary to the purpose for which it is intended,
- ▶ Damage can be attributed to not having followed the guidelines in the manual,
- ▶ Operating personnel are not suitably qualified,
- ▶ Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

3.4.4 Disposal

- ▶ In safety-related applications, please comply with the mission time T_M in the safety-related characteristic data.
- ▶ When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

4 Security

To secure plants, systems, machines and networks against cyberthreats it is necessary to implement (and continuously maintain) an overall industrial security concept that is state of the art.

Perform a risk assessment in accordance with VDI/VDE 2182 or IEC 62443-3-2 and plan the security measures with care. If necessary, seek advice from Pilz Customer Support.

4.1 Security (PSS u2 in the automation system PSS 4000)

Further information on Security can be found in the system description PSS 4000 (1001467).

5 Function description

5.1 Block diagram




Fig.: Block diagram-PSS u2 PS1 -R

5.2 Supply voltage

- ▶ Module supply
 - supplies voltage to the head module
 - supplies voltage to downstream modules (right-hand side)
- ▶ Periphery supply
 - supplies voltage to the sensors, actuators and test pulses

When the supply voltage is fed in separately, the module supply and periphery supply are galvanically isolated. If galvanic isolation is not required, a common power supply may be used for the periphery supply and module supply.

The module status is shown via the LED MS, see [Display elements and messages](#) [ 29].

5.2.1 Output power of module supply


However, please note

- ▶ the maximum output power of the module supply (see [Technical details \[31\]](#)).
- ▶ The total power consumption of the electronic modules and head module must not be higher than the max. output power of the main supply voltage module (see Module's technical details).
- ▶ The module supply is provided exclusively by the main supply voltage module.
- ▶ The module supply cannot be refreshed.
- ▶ The module supply does not automatically switch off if the max. output power is exceeded.
- ▶ The module supply's consumption is displayed when a PSS u2 system is configured.

Please refer to the **module supply's derating diagrams**.


Derating diagram for infeed for module supply: Permitted ambient temperature T dependent on power P .

Installation: Mounting position on the *mounting rail is horizontal* (see Installation Manual PSS u2 in the automation system PSS 4000)



Derating diagram for infeed for module supply: Permitted ambient temperature T dependent on power P .

Installation: Mounting position on the *mounting rail is vertical*, head module is assembled on top (see Installation Manual PSS u2 in the automation system PSS 4000)



5.2.2

Current load capacity of periphery supply

However, please note

- ▶ the maximum current load capacity of the periphery supply (see [Technical details \[31\]](#)).
- ▶ The current load capacity of the periphery supply is the sum of the current consumption of the sensors and actuators that are supplied via the input/output modules.
- ▶ If the total current consumption is higher than the current load capacity of the main supply voltage module, then the periphery supply must be refreshed using a periphery supply voltage module, in order to avoid overload.
- ▶ The periphery supply does not switch off automatically if the maximum current load capacity is exceeded.
- ▶ The periphery supply's consumption is displayed when a PSS u2 system is configured.

5.3 Integrated protection mechanisms

The module has the following protection mechanisms:

- ▶ Temperature monitoring
- ▶ Module supply
 - Polarity protection
 - Voltage monitoring
 - Transient voltage limitation
- ▶ Periphery supply
 - Polarity protection
 - Voltage monitoring

The periphery supply switches off if the level drops below 14 V.

The resulting diagnostic message can be switched off in the configuration tool PAS4000 in the **Module features**.

Select ***Suppress message about missing periphery supply***.

6 I/O data of the module (PSS u2 in the automation system PSS 4000)

When the electronic module for PSS u2 is used in the automation system PSS 4000, the data described below are available.

6.1 Available I/O data in the I/O mapping

Data access is via pre-defined I/O data types:

I/O data name	I/O data type	Data element: Data type	Meaning
PSPDiagnostics	ST_I_PSP_ DIAG	Status: ARRAY[0..1] OF BOOL	Status bits of the periphery supply (Bit 0 and Bit 1) 00: not relevant 01: Undervoltage de- tected 10: Periphery supply within the permitted range 11: Overvoltage de- tected
		SwitchedOn: BOOL	Switched on bit 0: Periphery supply switched off 1: Periphery supply switched on
		Overcurrent: BOOL	Overcurrent bit 0: No overcurrent 1: Overcurrent detec- ted
		ExtSupplyDetected: BOOL	External supply bit 0: No external supply on the backplane 1: External supply detected on the backplane
		VoltageOK: BOOL	Voltage tolerance bit 0: Periphery supply is outside the voltage tolerance 1: Periphery supply is within the voltage tolerance

6.2 Other I/O data

In addition to the I/O data available via I/O mapping, it is possible to access further I/O data in the user program:

- ▶ Valid bit of the date *PSPDiagnostics*

In the Multi programming, access is via the PSS 4000 system control block "Valid".

In IEC 61131 programming, access is via the variable extension "WITH VALID".

7 Installation

7.1 General installation guidelines



CAUTION!

Risk of material damage

Electrostatic discharge can damage components.

- Ensure against discharge before touching the product, e.g. by touching an earthed, conductive surface or by wearing an earthed arm-band.



CAUTION!

Risk of material damage

The incorrect ambient temperature during assembly/dismantling can lead to material damage.

- Comply with the permitted ambient temperature for assembly/dismantling: -20°C ... +45°C

7.1.1 Dimensions




Fig.: Dimensions PSS u2 PS1 -R

7.2 Insert and remove main voltage supply module

Please note:

- ▶ Backplane must be installed first.
- ▶ The protective plate is removed from the main voltage supply module and it is fixed on the last backplane.
- ▶ At least the first electronic module must not be installed on the backplane.
- ▶ Main voltage supply modules may only be plugged or unplugged if the terminal block has been removed first.
- ▶ The mechanics of the main voltage supply modules are designed for 20 plug in/out cycles.

7.3 Install backplane



CAUTION!


Risk of material damage

- Connect or remove the backplane only when the supply voltage is switched off.
- Switch off the supply voltage, before you connect or remove the backplane.

1. Insert the backplane on to the mounting rail. Leave enough distance [X] to the left to enable the head module plus the main supply voltage module to be installed. This distance will depend on the width of the head module plus main supply voltage module.

The mounting rail interlock must be in the open position, to the left.

2. Turn the mounting rail interlock to the right to lock the backplane on to the mounting rail.



7.4 Install protective plate




CAUTION!

Risk of material damage


Electrostatic discharge can damage components.

- Ensure that the yellow cover plate is fitted at the end of the backplane block. The yellow cover plate is an integral part of the main supply voltage module PSS u2 PS1 -R.

1. Remove the yellow cover plate from the main supply voltage module.



2. Attach the yellow ESD cover plate to the last backplane.



7.5 Insert main supply voltage module next to head module

Prerequisite

The terminal block is not wired.

1. From above, guide the main supply voltage module towards the right-hand side of the head module.



7.6 Install head module plus main voltage supply module

Prerequisite


The mounting rail must be installed.

The backplane is installed and the cover plate is installed.


1. Plug the head module plus main supply voltage module on to the mounting rail.

Note:

The mounting rail interlock must be in the open position, to the left.




2. Rotate the mounting rail interlocks to the right to lock the head module plus main supply voltage module on the mounting rail.




7.7 Insert terminal block

1. Insert the terminal block into the suspension lug on the module.



2. Swivel the terminal block upwards until you hear it click into place.



8 Wiring

8.1 General wiring guidelines

Please note:

- ▶ The requirements of the supply voltages can be found under "[Technical details !\[\]\(262a69471e6c1b2959997023f73bfe46_img.jpg\) 31](#)".
- ▶ Protective separation must be ensured for the external power supplies that generate the supply voltages. Failure to do so could result in electric shock.
- ▶ The supply voltages must be extra low voltages with safe electrical separation (PELV or SELV). The external power supplies must comply with EN 62368-1 and EN 61010-2-210.
- ▶ Please note that the normative requirements with a power failure of the supply voltage for module supply are fulfilled when using buffered external power supplies for creating the supply voltage.
- ▶ Connect the supply voltage correctly polarised.
- ▶ The maximum current load on the backplane for the periphery supply is 8 A.
- ▶ Earth the 0 V supply on the periphery supply or monitor each supply group for earth faults.
- ▶ The connection of the 0 V supply net to the central earth bar or earth fault monitoring must be in accordance with relevant national regulations (e.g. EN 60204-1).
- ▶ The minimum range for conductor cross sections on connection terminals can be found in chapter [Connection mechanism for terminal blocks !\[\]\(3f8eabbc5fbc831a822ddb57fc80787d_img.jpg\) 26](#).
- ▶ Use copper wiring.

8.1.1 Connection mechanism for terminal blocks

Please note:

- ▶ The minimum cable cross section for field connection terminals on the terminal blocks is 0.15 mm² (AWG26).
- ▶ The maximum cable cross section for field connection terminals on the terminal blocks is 1.5 mm² with ferrules (AWG14)
- ▶ Use copper wiring.

Procedure:

- ▶ Use a flat head screwdriver.
- ▶ Strip the wire back 9 mm.
- ▶ Feed the stripped cable as far as it will go into the opening for the spring-loaded terminal.
- ▶ Check that the cable is firmly seated.

8.2 Terminal configuration

8.2.1 Connecting the module




Fig.: Separate power supplies for module supply and periphery supply




Fig.: Common power supply for module supply and periphery supply

Use the following fuses:


Module supply: max. 6 A characteristic B/C

Periphery supply: max. 8 A characteristic B/C

9 Operation

The status of the module is displayed via the "Module status" LED; this is signalled to the head module and any error is entered in the head module's diagnostic log.

9.1 Display elements and messages



Legend

[1] Module status display

The module can detect the following errors:

LED [1] MS	Colour LED [1]	Meaning	Further information
	--	Module not ready for operation	
	Green	Module ready for operation	
	Green	Module in operation	
	Red	▶ Periphery supply error (undervoltage/overvoltage/overload)^[1] ▶ Error in the module supply (undervoltage) ▶ Overtemperature^[2]	See module's diagnostic log
	Red	Internal errors	See module's diagnostic log

Legend



LED on



LED flashes



LED off

^[1] With the voltage supply module it is possible to suppress the diagnostic messages that are displayed with undervoltage of the periphery supply or when the infeed of the periphery supply is missing. When the diagnostic messages are suppressed, the red flashing of the module status LED is also suppressed.

- ▶ In the configuration tool PAS4000, in the properties of the module on the in the **PSS u2 system** tab, activate the option **Suppress message about missing periphery supply**.

^[2] There are two levels of overtemperature.

- ▶ Too warm:

If the module temperature exceeds a threshold value, then:

- a warning is sent to the head module.

If the temperature drops back below the threshold value, the module sends an all-clear.

- ▶ Too hot:

If the module temperature exceeds another threshold value, then:

- an error message is sent to the head module.

After the "too hot" message has been received, if the temperature drops back below the "too warm" threshold value, the module will switch to an error-free state.

10 Technical details

General	
Certifications	CE, TÜV
Application range	Standard
Module's device code	2C02h
Number of ST input bits	6
Number of ST status bits	6
Electrical data	
Supply voltage	
for	Module supply
Voltage	24 V
Kind	DC
Voltage tolerance	-30 %/+25 %
Output of external power supply (DC)	31 W
Output of external power supply (DC) at no load	3 W
Max. output power	25 W
Residual ripple DC	5 %
Buffer time	5 ms
Supply voltage	
for	Periphery supply
Voltage	24 V
Kind	DC
Voltage tolerance	-30 %/+25 %
Current load capacity at UB	8 A
Output of external power supply (DC)	192 W
Output of external power supply (DC) at no load	0,5 W
Residual ripple DC	5 %
Potential isolation	Yes
Internal supply voltage (module supply)	
Module's power consumption	2,5 W
Environmental data	
Application site	
in accordance with the standard	EN 50125-3
Application site	Track area (1 m - 3 m)
Climatic suitability	EN 60068-2-1, EN 60068-2-14, EN 60068-2-2, EN 60068-2-30, EN 60068-2-78
Ambient temperature	
in accordance with the standard	EN 60068-2-14
Temperature range	-40 - 70 °C
Storage temperature	
in accordance with the standard	EN 60068-2-1/-2
Temperature range	-40 - 70 °C

Environmental data

Climatic suitability	
in accordance with the standard	EN 50125-3
Humidity	95 % r. h. at 40 °C
Condensation during operation	EN 60068-2-30
Max. operating height above SL	5000 m
EMC	EN 50121-4, EN 61000-6-2, EN 61000-6-4, EN 61131-2 (Zone B)
Broadband noise	
in accordance with the standard	EN 60068-2-64
Frequency	5 - 2.000 Hz
Acceleration	2,3 m/s² eff.
Shock stress	
in accordance with the standard	EN 60068-2-27
Number of shocks	6
Acceleration	20 m/s²
Duration	11 ms
Airgap creepage	
in accordance with the standard	EN 61131-2
Overvoltage category	II
Pollution degree	2
in accordance with the standard	EN 50124-1
Overvoltage category	OV2
Pollution degree	PD2
Protection type	
in accordance with the standard	EN 60529
Housing	IP20
Terminals	IP20
Mounting area (e.g. control cabinet)	IP51

Potential isolation

Potential isolation between	Supply voltage for module supply and periphery supply
Type of potential isolation	Functional insulation
Rated surge voltage in operating heights up to max. 2000 m	2000 V
Rated surge voltage in operating heights up to max. 5000 m	1500 V
Potential isolation between	Supply voltage for module supply and module supply
Type of potential isolation	Functional insulation
Rated surge voltage in operating heights up to max. 2000 m	2000 V
Rated surge voltage in operating heights up to max. 5000 m	1500 V
Potential isolation between	Periphery supply and module supply
Type of potential isolation	Functional insulation

Potential isolation

Rated surge voltage in operating heights up to max. 2000 m	2000 V
---	---------------

Rated surge voltage in operating heights up to max. 5000 m	1500 V
---	---------------

Mechanical data

Material

Housing	PC
---------	-----------

Connection type	Spring-loaded terminal
-----------------	-------------------------------

Mounting type	plug-in
---------------	----------------

Dimensions

Height	109,3 mm
--------	-----------------

Width	31,3 mm
-------	----------------

Depth	95,4 mm
-------	----------------

Weight	138 g
--------	--------------

Where standards are undated, the 2022-01 latest editions shall apply.

11 Supplementary data

11.1 Permitted operating height

The values stated in the technical details apply to the use of the device in operating heights up to max. 2000 m above SL. When used at higher levels, restrictions of the ambient temperature (standard IEC 61131-2) must be taken into account.

Operating height above SL [m]	Multiplication factors for the devices' ambient temperature
0 ... 2000	1.0
3000	0.9
4000	0.8
5000	0.7

12 Order reference

12.1 Product

Product type	Features	Order no.
PSS u2 PS1 -R	Main voltage supply module for PSS u2 head module for connecting module supply and periphery supply, connection for functional earth, potential isolation, for increased environmental requirements and railway applications	329302

12.2 Accessories

Terminal block

Product type	Features	Order no.
PSS u2 T 9	Terminal block 9-pin for main voltage supply PSS u2 PSx	328832

Label holder for terminal block

Product type	Features	Order no.
PSS u2 A LC T3 (10 pcs.)	Label holder for terminal block 61 x 11.5 mm, scope of delivery: 10 pieces	328912

Labelling bracket

Product type	Features	Order no.
PSS u2 A LC E1 (10 pcs.)	Label holder for electronic module 23.5 x 10.5 mm, scope of delivery: 10 pieces	328910
PSS u2 A LC E2 (10 pcs.)	Label holder for electronic module 103 x 10.5 mm, scope of delivery: 10 pieces	328911
PSS u2 A LA E1 (10 pcs.)	Labelling strips for electronic module 23.5 x 10.5 mm (10 x DIN A4 sheet)	328913
PSS u2 A LA E2 (10 pcs.)	Labelling strips for electronic module 103 x 10.5 mm (10 x DIN A4 sheet)	328914

Support

Technical support is available from Pilz round the clock.

Americas

Brazil

+55 11 97569-2804

Canada

+1 888 315 7459

Mexico

+52 55 5572 1300

USA (toll-free)

+1 877-PILZUSA (745-9872)

Asia

China

+86 21 60880878-216

Japan

+81 45 471-2281

South Korea

+82 31 778 3300

Australia and Oceania

Australia

+61 3 95600621

New Zealand

+64 9 6345350

Europe

Austria

+43 1 7986263-0

Belgium, Luxembourg

+32 9 3217570

France

+33 3 88104003

Germany

+49 711 3409-444

Ireland

+353 21 4804983

Italy, Malta

+39 0362 1826711

Scandinavia

+45 74436332

Spain

+34 938497433

Switzerland

+41 62 88979-32

The Netherlands

+31 347 320477

Turkey

+90 216 5775552

United Kingdom

+44 1536 462203

**You can reach our
international hotline on:**

+49 711 3409-222

support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.



CECE®, CHRE®, CMSE®, InduraNET p®, Leansafe®, Master of Safety®, PAS4000®, PAScale®, PASconfig®, Pilz®, PIR®, PLID®, PMCPirimo®, PMCPiritego®, PMCTendo®, PMD®, PMJ®, PNOZ®, PRM®, PRMNET p®, PRMNET p®, PSS®, PVS®, SafetyBUS p®, SafetyNET p®, THE SPIRIT OF SAFETY® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries. We would point out that product features may vary from the details stated in this document, depending on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirety of the text and graphics presented in this information. Please contact our Technical Support if you have any questions.

1006251-EN-01, 2023-04 Printed in Germany
© Pilz GmbH & Co. KG, 2019

We are represented internationally. Please refer to our homepage www.pilz.com for further details or contact our headquarters.

Headquarters: Pilz GmbH & Co. KG, Felix-Wankel-Straße 2, 73760 Ostfildern, Germany
Telephone: +49 711 3409-0, Telefax: +49 711 3409-133, E-Mail: info@pilz.com, Internet: www.pilz.com

PILZ
THE SPIRIT OF SAFETY