



► PSEN in-D-A-N

PILZ
THE SPIRIT OF SAFETY

Operating Manual-1006710-EN-03
- PSEN sensor technology



This document is the original document.

Where unavoidable, for reasons of readability, the masculine form has been selected when formulating this document. We do assure you that all persons are regarded without discrimination and on an equal basis.

All rights to this documentation are reserved by Pilz GmbH & Co. KG. Copies may be made for the user's internal purposes. Suggestions and comments for improving this documentation will be gratefully received.

Pilz®, PIT®, PMI®, PNOZ®, Primo®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, the spirit of safety® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries.



SD means Secure Digital

1	Introduction	5
1.1	Validity of documentation	5
1.2	Using the documentation	5
1.3	Definition of symbols	5
2	Safety	7
2.1	Intended use	7
2.2	Safety regulations	7
2.2.1	Safety assessment	7
2.2.2	Use of qualified personnel	8
2.2.3	Warranty and liability	8
2.2.4	Disposal	8
3	Product features	9
4	Function description	10
4.1	Overview	10
4.2	Function	10
4.3	LED status and error display	11
4.4	Block diagram	11
4.5	Operating distances	12
4.6	Type code	13
5	Wiring	14
5.1	Important information	14
5.2	Pin assignment, connector and connection cable	14
6	Connection to evaluation devices	15
6.1	Suitable Pilz evaluation devices	15
6.2	Evaluation of an inductive proximity switch, dual-channel	16
6.3	Evaluation of two inductive proximity switches, dual-channel	17
6.4	Evaluation of one inductive proximity switch, single-channel	18
7	Installation	19
7.1	Important information	19
7.2	Installation conditions (distances)	20
7.2.1	Sensing face forward	20
7.2.2	Sensing face upwards	20
7.3	Installation	21
7.4	Installation of manipulation protection	21
8	Operation	22
8.1	LED status and error display	23
8.2	Prior to commissioning	24

9	Regular checks	25
10	Dimensions in mm	26
10.1	PSEN in-D-A-N	26
11	Technical details	27
12	Safety characteristic data	29
13	Order reference	31
13.1	Product.....	31
13.2	Accessories.....	31
13.2.1	Connection cable, 5-pin	31
13.2.2	Connection cable, 4-pin	32
13.2.3	Manipulation protection	32
14	EC declaration of conformity	33
15	UKCA-Declaration of Conformity	34

1 Introduction

1.1 Validity of documentation

This documentation is valid for the product PSEN in-D-A-N. It is valid until new documentation is published.

This operating manual explains the function and operation, describes the installation and provides guidelines on how to connect the product.

1.2 Using the documentation

This document is intended for instruction. Only install and commission the product if you have read and understood this document. The document should be retained for future reference.

1.3 Definition of symbols

Information that is particularly important is identified as follows:



DANGER!

This warning must be heeded! It warns of a hazardous situation that poses an immediate threat of serious injury and death and indicates preventive measures that can be taken.



WARNING!

This warning must be heeded! It warns of a hazardous situation that could lead to serious injury and death and indicates preventive measures that can be taken.



CAUTION!

This refers to a hazard that can lead to a less serious or minor injury plus material damage, and also provides information on preventive measures that can be taken.



NOTICE

This describes a situation in which the product or devices could be damaged and also provides information on preventive measures that can be taken. It also highlights areas within the text that are of particular importance.



INFORMATION

This gives advice on applications and provides information on special features.

2 Safety

2.1 Intended use

The safety functions of the safe inductive proximity switch are:

- ▶ The inductive proximity switch signals the safe state when the damping material (electrically conductive object) is outside the assured release distance S_{ar} .
- ▶ The safe state of the inductive proximity switch is the high impedance state (off-state).
- ▶ Safety functions on which the low impedance state (on-state) is the safe state were not evaluated.
- ▶ A dangerous failure is present when the inductive proximity switch does not signal the safe state.

The safe inductive proximity switch meets the requirements in accordance with:

- ▶ EN ISO 13849-1:2023 (up to Cat. 4 PL e)
- ▶ EN IEC 61508-1:2010 (up to SIL 3)
- ▶ EN IEC 62061:2021 (max. SIL 3)
- ▶ EN IEC 60947-5-3:2013

Improper use

The following is deemed improper use in particular:

- ▶ Any component, technical or electrical modification to the product,
- ▶ Use of the product outside the areas described in this operating manual,
- ▶ Use of the product outside the technical details (see chapter entitled [Technical Details](#) [ 27]).



NOTICE

EMC-compliant electrical installation

The product is designed for use in an industrial environment. The product may cause interference if installed in other environments. If installed in other environments, measures should be taken to comply with the applicable standards and directives for the respective installation site with regard to interference.

2.2 Safety regulations

2.2.1 Safety assessment

Before using a product, a risk assessment in accordance with the Machinery Directive is required.

The product as an individual component fulfils the functional safety requirements in accordance with EN/IEC 61508, EN ISO 13849-1/2 and EN IEC 62061. However, this does not guarantee the functional safety of the overall plant/machine. To achieve the relevant safety level of the overall plant/machine's required safety functions, each safety function needs to be considered separately.

It is the responsibility of the user/operator to carry out a risk assessment for their application, in which they consider the impact of assumed errors in the wiring and take appropriate measures to control or avoid these errors.

2.2.2 Use of qualified personnel

The products may only be assembled, installed, programmed, commissioned, operated, decommissioned and maintained by persons who are competent to do so.

A competent person is a qualified and knowledgeable person who, because of their training, experience and current professional activity, has the specialist knowledge required. In order to inspect, assess and handle products, devices, systems, plant and machinery, this person must be familiar with the state of the art and the applicable national, European and international laws, directives and standards.

It is the company's responsibility only to employ personnel who

- ▶ Are familiar with the basic regulations concerning health and safety / accident prevention,
- ▶ Have read and understood the information provided in the section entitled Safety
- ▶ Have a good knowledge of the generic and specialist standards applicable to the specific application.

2.2.3 Warranty and liability

All claims to warranty and liability will be rendered invalid if

- ▶ The product was used contrary to the purpose for which it is intended,
- ▶ Damage can be attributed to not having followed the guidelines in the manual,
- ▶ Operating personnel are not suitably qualified,
- ▶ Any type of modification has been made (e.g. exchanging components on the PCB boards, soldering work etc.).

2.2.4 Disposal


- ▶ In safety-related applications, please comply with the mission time T_M stated in the safety-related characteristic data.
- ▶ When decommissioning, please comply with local regulations regarding the disposal of electronic devices (e.g. Electrical and Electronic Equipment Act).

3 Product features

- ▶ Operation Inductive
- ▶ Cubic design
- ▶ 4-pin M12 male connector
- ▶ 2 OSSD safety outputs
- ▶ LED status and error display

4 Function description

4.1 Overview



Legend

A PSEN in-D-A-N

B Damping material (electrically conductive object)

[1] 4-pin M12 male connector

[2] Fastening element

[3] LED status display

[4] LED error display

[5] Sensing face

4.2 Function

If damping material (electrically conductive object) is within the response range of the coil on the safe inductive proximity switch, the coil's magnetic field is influenced. This change of the magnetic field generates an electrical switch signal and transmits it to the connected evaluation device.

The safe inductive proximity switch has 2 OSSD safety outputs. A high signal (on-state) or low signal (off-state) is present at the OSSD safety outputs, depending on the state of the magnetic field of the coil within the response range. The OSSD safety outputs switch to the off-state (low signal) in accordance with their defined behaviour under fault conditions (PDDb).


If there is no damping material (electrically conductive object) within the response range of the coil, the OSSD safety outputs are in the off-state (LOW signal). The OSSD safety outputs are compatible with inputs of type 1, 2 or 3 in accordance with EN 61131-2.

State of OSSD safety outputs

Damping material (electrically conductive object) within the response range of the coil	Safety output OSSD 1	Safety output OSSD 2
Yes	High signal (on-state)	High signal (on-state)
No	Low signal (off-state)	Low signal (off-state)

4.3 LED status and error display


LED status display lights up yellow when the safety outputs are in the on-state. LED error display lights up red when an error occurs.

4.4 Block diagram**Legend**

[1] Damping material (electrically conductive object)

Connection designation	Function
A1	+24 V
A2	0 V
12	Safety output OSSD 1
22	Safety output OSSD 2

4.5 Operating distances



Legend

[1] PSEN in-D-A-N

[2] Sensing face

[3] Damping material (electrically conductive object)

a Base = 0 mm

b Current distance to damping material

s_n Rated operating distance

s_{ar} Assured release distance

The following operating distances were determined using a standard measuring plate (material FE 360) in accordance with EN IEC 60947-5-2.

Type	PSEN in-A-A-D
Installation conditions	Flush
Dimensions of the standard measuring plate in accordance with EN IEC 60947-5-2 (a x b x c)	45 mm x 45 mm x 1 mm
Rated operating distance s_n	15 mm
Assured release distance s_{ar}	22.5 mm
Safety reaction time ^[1]	≤ 80 ms
Reduction factor r_{Al} ^[2]	0.40
Reduction factor r_{Cu} ^[2]	0.35
Reduction factor $r_{V2A (1.4301)}$ ^[2]	0.90
Reduction factor r_{Ms} ^[2]	0.45

^[1] The safety reaction time is the maximum time, without error, that is needed from removal of the standard measuring plate to the reaction of the OSSD safety outputs in normal operation.

^[2] If a material other than FE 360 is used, the specified switching distances may change by one factor.

4.6 Type code

The type code of the safe inductive proximity switch "PSEN in-X-X-X" is composed as follows:

Product area (PSEN)	Product group (in-)	Housing (X-)	Installation condition (X-)	Connection (X)
Pilz SENsor	Inductive proximity switch	D	A Flush	N 4-pin M12 male connector, A coded

5 Wiring

5.1 Important information

- ▶ Information given in the [Technical details \[27\]](#) must be followed.
- ▶ Calculation of the max. cable length $l_{\max}$ in the input circuit:


$$l_{\max} = \frac{R_{l\max}}{R_l / \text{km}}$$

$R_{l\max}$ = max. overall cable resistance (see under "[Technical details \[27\]](#)")

R_l / km = cable resistance/km

- ▶ The power supply must meet the regulations for extra low voltages with protective electrical separation (SELV, PELV).
- ▶ The power supply must have an overvoltage protection of $\leq 35 \text{ V DC}$.
- ▶ The OSSD safety outputs of the safe inductive proximity switch must have protective separation from voltages over 35 VDC.
- ▶ The supply voltage of the safety inductive proximity switch must be protected with a 2 A to 4 A quick-acting fuse.
- ▶ Ensure the wiring and EMC requirements of EN 60204-1 are met.

5.2 Pin assignment, connector and connection cable

	4-pin M12 male connector
---	--------------------------

PIN	Connection designation	Function	Wire colour
1	A1	+24 V	Brown
2	22	Safety output OSSD 2	White
3	A2	0 V	Blue
4	12	Safety output OSSD 1	Black

The wire colour applies for the connection cables available from PILZ as an accessory.

6 Connection to evaluation devices

The safe inductive proximity switch can be connected to suitable evaluation devices and evaluated.

6.1 Suitable Pilz evaluation devices

Suitable Pilz evaluation devices are, for example:

- ▶ myPNOZ
- ▶ PNOZmulti
- ▶ PSS 4000

These Pilz evaluation devices have a partial operation lock and need less than 30 mA in the input circuit.

The correct connection to the respective Pilz evaluation device is described in the corresponding operating manual. Ensure that the connection is made in accordance with these specifications.




Fig.: Example illustration with PNOZmulti

Legend

[1] PNOZmulti


[2] PSEN in-D-A-N

[a] White connection cable

[b] Black connection cable

Connection designation	Function
A1	+24 V
A2	0 V
12	Safety output OSSD 1
22	Safety output OSSD 2

6.2 Evaluation of an inductive proximity switch, dual-channel



Legend

- | | |
|-----------------------|-------------------|
| [1] Damping material | [2] PSEN in-D-A-N |
| [3] Evaluation device | (FS) Failsafe |

Ensure that the selected evaluation device has the following properties:


- dual-channel with plausibility check (partial operation lock):

In an input circuit it is necessary to check, when outputs (12, 22) are evaluated, whether both outputs (12, 22) actually switch off in compliance with the discrepancy time. If this is not the case, a partial operation lock of the evaluation device must be activated.

- Maximum achievable performance level of the safety circuit:

PL d, Cat. 2, SIL 2

6.3 Evaluation of two inductive proximity switches, dual-channel



Legend

- | | |
|-----------------------|-------------------|
| [1] Damping material | [2] PSEN in-D-A-N |
| [3] Evaluation device | (FS) Failsafe |

Ensure that the selected evaluation device has the following properties:


- ▶ dual-channel with plausibility check (partial operation lock):

In an input circuit it is necessary to check, when outputs (12) are evaluated, whether both outputs (12) actually switch off in compliance with the discrepancy time. If this is not the case, a partial operation lock of the evaluation device must be activated.

- Maximum achievable performance level of the safety circuit:

PL e, Cat. 4, SIL 3

6.4 Evaluation of one inductive proximity switch, single-channel



Legend

[1] Damping material

[2] PSEN in-D-A-N

[3] Evaluation device

(FS) Failsafe

Ensure that the selected evaluation device has the maximum achievable performance level of the safety circuit, SIL 2.

7 Installation

7.1 Important information



WARNING!

If the supply voltage to the safe inductive proximity switch exceeds 35 VDC in the case of an error, the safety function is no longer guaranteed.

People can access a machine's danger zone. There is an increased risk of injury or even a threat to life!

- Ensure that the supply voltage of 35 VDC is not exceeded.



WARNING!

If damping material (electrically conductive object) unintentionally reaches the response range of the coil on the safe inductive proximity switch, the safety function is no longer guaranteed.

People can access a machine's danger zone. There is an increased risk of injury or even a threat to life!

- Ensure that only the intended damping material (electrically conductive object) reaches the response range of the coil on the safe inductive proximity switch. Only then is the safety function guaranteed.
- Check the assured operating distance s_a and the assured release distance s_{ar} .

- ▶ Be aware of the installation and environmental conditions.
- ▶ Use appropriate design measures to ensure that no damping material (electrically conductive object), such as metals in the form of swarf, screws, plates, etc., can reach the vicinity of the safe inductive proximity switch.
- ▶ When installing, ensure you comply with the requirements of EN ISO 14119.
- ▶ Check the operating distances under real conditions.
- ▶ Check the operating distances regularly, see "[Regular checks](#)  25".
- ▶ Check the operating distances each time the application is changed.
- ▶ Ensure that the safe inductive proximity switch cannot be used as a limit stop.
- ▶ Attach the safe inductive proximity switch as described below. Please note the stated torque settings.

7.2 Installation conditions (distances)



7.2.1 Sensing face forward

$X \geq 0 \text{ mm}$	$X \geq 0 \text{ mm}$	$Y \geq 0 \text{ mm}$
-	-	$A = \text{any}$

$Y \geq 0 \text{ mm}$	$B \geq 45 \text{ mm}$	$X \geq 60 \text{ mm}$
$A = \text{any}$	$Y \geq 40 \text{ mm}$	-

7.2.2 Sensing face upwards

$X \geq 0 \text{ mm}$	$Y \geq 0 \text{ mm}$	$Y \geq 0 \text{ mm}$
-	$A \leq 40 \text{ mm}$	$A \leq 40 \text{ mm}$

		-
$Y \geq 5 \text{ mm}$	$Y \geq 10 \text{ mm}$	-
$A = \text{any}$	$A = \text{any}$	-

7.3

Installation




WARNING!

If the sensor is not installed correctly on the mounting plate, the sensor may slip. Then the safety function is no longer guaranteed.

People can access a machine's danger zone. There is an increased risk of injury or even a threat to life!

- Ensure that the sensor is installed correctly on the mounting plate.



1. Screw the safe inductive proximity switch [3] into the prepared thread in the mounting plate [2] using the two screws [1].
2. Tighten the two screws [1]. Please note the torque setting of the screws [1]:
⇒ Torque setting 15 Nm

7.4

Installation of manipulation protection

You can also attach manipulation protection to guard against unauthorised loosening/removal of the threaded connector on the connection cable. For order reference see accessories "[Manipulation protection](#) [ 32]".

8 Operation



WARNING!

If you do not check the safety function of the safe inductive proximity switch after the initial commissioning or after making a change, it is possible that the safety function will not work properly.

People can access a machine's danger zone. There is an increased risk of injury or even a threat to life!

- Ensure that the safety function of the safe inductive proximity switch is checked by a qualified professional after the initial commissioning and after each change.



WARNING!

If the safety circuit of the safe, inductive proximity switch is taken out of service, the safety function will be without function.

People can access a machine's danger zone. There is an increased risk of injury or even a threat to life!

- Do not deactivate the safe inductive proximity switch.
- Do not defeat the safety function of the safe inductive proximity switch.
- Do not repair, modify or manipulate the safe inductive proximity switch.



WARNING!

If damping material (electrically conductive object) unintentionally reaches the response range of the coil on the safe inductive proximity switch, the safety function is no longer guaranteed.

People can access a machine's danger zone. There is an increased risk of injury or even a threat to life!

- Ensure that only the intended damping material (electrically conductive object) reaches the response range of the coil on the safe inductive proximity switch. Only then is the safety function guaranteed.
- Check the assured operating distance s_a and the assured release distance s_{ar} .

The safe inductive proximity switch has no blind spot in which the function is unsafe. Any failures are displayed via the OSSD safety outputs and via the dual-colour LED status display.

8.1 LED status and error display



Legend

1 LED status display

2 LED error display

LED status display

Operating state	OSSD 1/2	LED
Damping material (electrically conductive object) within the assured operating distance s_a	On	Yellow
Damping material (electrically conductive object) within the assured release distance s_{ar}	Off	Off

LED error display

Operating state	OSSD 1/2	LED
No power supply	Off	Off
Switching on after applying power	Off	Flashes red ^[1]
Undervoltage/overvoltage	Off	Red
Short between contacts ^[2]	At least one OSSD safety output is switched off ^[3]	Red
Internal error detected	At least one OSSD safety output is switched off ^[3]	Red

^[1] The LED flashes only once.

^[2] A short between contacts is a short circuit between the outputs or between an output and the supply. The error is detected and displayed immediately or at the next switching operation, depending on the short between contacts.

The error means that at least one output is switched permanently to the safe state (off-state). The safe state is cancelled when the error state is exited and the voltage supply is switched off and then on again.

- [3] The error means that at least one OSSD safety output is switched permanently to the safe state (off-state). The safe state is displayed via the LED status indicator. The safe state is cancelled when the error state is exited and the voltage supply is switched off and then on again.

8.2 Prior to commissioning

Check the function of the safe inductive proximity switch prior to commissioning:

1. Bring the damping material (electrically conductive object) up to the sensing face of the safe inductive proximity switch (see [Operating distances](#) [ 12]), until the LED status display lights up yellow.
2. Move the damping material (electrically conductive object) at least as far as the assured release distance s_{ar} . The LED status display must go out.
3. If the LED status display does not go out:
Check that the safe inductive proximity switch is installed correctly.

9

Regular checks

Regular checks can bring to light changes to the plant/machine, safeguards and ambient conditions.



INFORMATION

Checks may only be performed by qualified personnel.



NOTICE


Only Pilz may repair the product.

Any guarantee is rendered invalid if the housing is opened or unauthorised modifications are carried out.

- ▶ Test intervals (in accordance with EN ISO 14119)
 - At least monthly for PL e
 - At least every 12 months for PL d
- ▶ Check that the safe inductive proximity switch is seated firmly.
Tighten the nuts using the appropriate torque setting.
- ▶ Remove any dirt from the safe inductive proximity switch and damping material (electrically conductive object).
- ▶ Check the safe inductive proximity switch for any damage.
Swap any safe inductive proximity switch that is damaged.
- ▶ Check that the safe inductive proximity switch is working correctly.
If the safe inductive proximity switch is not working correctly, swap it.

10 Dimensions in mm

10.1 PSEN in-D-A-N



11 Technical details

Where standards are undated, the 2019-11 valid editions apply.

General	
Certifications	CE, TÜV, UKCA, cULus Listed
Sensor's mode of operation	Inductive
Electrical data	
Supply voltage	
Voltage	24 V
Kind	DC
Voltage tolerance	-25 %/+25 %
Max. switching frequency	10 Hz
Max. cable capacitance at the safety outputs	
No-load, PNOZ with relay contacts	20 nF
PNOZmulti, PNOZelog, PSS	20 nF
Max. overall cable resistance R _{lmax}	10 Ohm
Rated operating voltage	24 V DC
No-load current	15 mA
Semiconductor outputs	
OSSD safety outputs	2
Switching current per output	30 mA
Short circuit-proof	Yes
Residual current at outputs	500 µA
Times	
Switch-on delay	
after UB is applied	0,3 s
Environmental data	
Ambient temperature	
Temperature range	-25 - 70 °C
Storage temperature	
Temperature range	-40 - 85 °C
Max. operating height above SL	2000 m
Rated insulation voltage	30 V
Protection type	
Housing	IP68, IP69
Operating distances	
Assured operating distance S _a	12,15 mm
Assured release distance S _{ar}	22,5 mm
Rated operating distance S _n	15 mm
Typ. hysteresis in relation to the rated operating distance S _n	5 %

Mechanical data

Sensor flush installation in accordance with EN 60947-5-2

Yes

Connection type

M12, 4-pin

Material

Housing

Metal Xylan-coated

Front

PA-GF35

Top

PA-GF35

Dimensions

Height

40 mm

Width

60 mm

Depth

40 mm

Weight

192 g

12 Safety characteristic data



NOTICE

You must comply with the safety characteristic data in order to achieve the required safety level for your plant/machine.

Parameter	Characteristic data		
Assessment type and documentation	Full assessment		
Operating mode	Low demand mode, high demand mode or continuous mode		
HFT	0	1	0
Safety function	Safety circuit via the OSSD1 and OSSD2 outputs of one sensor (1oo2)	Safety circuit via the OSSD1 outputs of two sensors (1oo2)	Safety circuit via the OSSD1 outputs of one sensor (1oo1)
SIL	2	3	2
SIL _{CL}	2	3	2
SC	3	3	3
Category	2	3/4^[1]	-
PL	d	e	-
Function test interval	Maximum 1 year	-	-
$\lambda_s^{[2]}$	36.8 FIT	74 FIT	36.8 FIT
λ_{dd}	25.7 FIT	79 FIT	21.3 FIT
λ_{du}	14.9 FIT	1.93 FIT	19.3 FIT
SFF ^[2]	80%	98.7%	75%
DC	63% (low)	97.6% (average)	52%
MTBF ^[3]	557 Years	278 Years	557 Years
MTTF _D	7600 Years	59000 Years	5900 Years
PFH	1.49×10^{-8} 1/h	1.93×10^{-9} 1/h	1.93×10^{-8} 1/h
PFD _{avg} for T ₁ = 1 year	6.51×10^{-5}	8.44×10^{-6}	8.44×10^{-5}
PFD _{avg} for T ₁ = 20 years	1.30×10^{-3}	1.69×10^{-4}	1.69×10^{-3}
Error reaction time ^[4]	< 200 ms	< 5 ms	< 5 ms
T _M ^[5]	Maximum 20 years		

^[1] Ensure that both sensors switch if called upon. The safety circuit can achieve Category 3 or 4, depending on the structure of the following circuit. The safe evaluation device must be able to activate the partial operation lock function.

^[2] "No impact failures" do not affect the safety function and so are not included in SFF, nor in the safety function's failure rate.

^[3] in accordance with SN29500.

This value contains failures that are not part of the safety function/MTTR = 24 h. This value is calculated for one safety function on the product.

^[4] Time between error occurring and error reaction, including detection of shorts across contacts.

^[5] T_M is the maximum mission time in accordance with EN ISO 13849-1. The value also applies as the retest interval in accordance with EN IEC 61508-6 and EN IEC 61511 and as the proof test interval and mission time in accordance with EN IEC 62061.

All the units used within a safety function must be considered when calculating the safety characteristic data.



INFORMATION

A safety function's SIL/PL values are **not** identical to the SIL/PL values of the products used and may differ from these.

13 Order reference

13.1 Product

Product type	Features	Order no.
PSEN in-D-A-N	Safe inductive proximity switch, 2 OSSD safety outputs, cubic design, operating distance 15 mm flush, 4-pin M12 male connector	6P000004

13.2 Accessories

13.2.1 Connection cable, 5-pin

You can use 5-pin connection cables if you wish to connect the evaluation device using an M12 connector. The extra pin is not used.

Product type	Features	Order no.
PDP67 cable M12-5sf M12-5sm, 1m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 1 m	380711
PDP67 cable M12-5sf M12-5sm, 1.5m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 1.5 m	380712
PDP67 cable M12-5sf M12-5sm, 2m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 2 m	380713
PSS67 cable M12sf M12sm, 3m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 3 m	380208
PSS67 cable M12sf M12sm, 5m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 5 m	380209
PSS67 cable M12sf M12sm, 10m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 10 m	380210
PSS67 cable M12-5sf M12-5sm, 20m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 20 m	380220
PSS67 cable M12sf M12sm, 30m	Connection cable, PUR, yellow RAL1003, 5-pin, straight M12 socket, on straight M12 connector, A-coded, cable length: 30 m	380211
PSS67 cable M12af M12am, 3m	Connection cable, PUR, yellow RAL1003, 5-pin, angled M12 socket, on angled M12 connector, A-coded, cable length: 3 m	380212
PSS67 cable M12af M12am, 5m	Connection cable, PUR, yellow RAL1003, 5-pin, angled M12 socket, on angled M12 connector, A-coded, cable length: 5 m	380213
PSS67 cable M12af M12am, 10m	Connection cable, PUR, yellow RAL1003, 5-pin, angled M12 socket, on angled M12 connector, A-coded, cable length: 10 m	380214
PSS67 cable M12af M12am, 30m	Connection cable, PUR, yellow RAL1003, 5-pin, angled M12 socket, on angled M12 connector, A-coded, cable length: 30 m	380215

13.2.2 Connection cable, 4-pin

If you are using the 4-pin connection cable, the evaluation device must be connected to the open cable ends.

Product type	Features	Order no.
PSEN op cable axial M12 4-pole 3m	Connection cable, PUR, yellow RAL1003, 4-pin, straight M12 socket, on open cable end, A-coded, cable length: 3 m	630300
PSEN op cable axial M12 4-pole 5m	Connection cable, PUR, yellow RAL1003, 4-pin, straight M12 socket, on open cable end, A-coded, cable length: 5 m	630301
PSEN op cable axial M12 4-pole 10m	Connection cable, PUR, yellow RAL1003, 4-pin, straight M12 socket, on open cable end, A-coded, cable length: 10 m	630302
PSEN op cable axial M12 4-pole 30m	Connection cable, PUR, yellow RAL1003, 4-pin, straight M12 socket, on open cable end, A-coded, cable length: 30 m	630296
PSEN op cable axial M12 4-pole 50m	Connection cable, PUR, yellow RAL1003, 4-pin, straight M12 socket, on open cable end, A-coded, cable length: 50 m	630362
PSEN op cable angle M12 4-pole 3m	Connection cable, PUR, yellow RAL1003, 4-pin, angled M12 socket, on open cable end, A-coded, cable length: 3 m	630341
PSEN op cable angle M12 4-pole 5m	Connection cable, PUR, yellow RAL1003, 4-pin, angled M12 socket, on open cable end, A-coded, cable length: 5 m	630342
PSEN op cable angle M12 4-pole 10m	Connection cable, PUR, yellow RAL1003, 4-pin, angled M12 socket, on open cable end, A-coded, cable length: 10 m	630343
PSEN op cable angle M12 4-pole 30m	Connection cable, PUR, yellow RAL1003, 4-pin, angled M12 socket, on open cable end, A-coded, cable length: 30 m	630344
PSEN op cable angle M12 4-pole 50m	Connection cable, PUR, yellow RAL1003, 4-pin, angled M12 socket, on open cable end, A-coded, cable length: 50 m	630363

13.2.3 Manipulation protection

Product type	Features	Order no.
CABLE/M12/CLIP	Manipulation protection for plug-in connector and protection against unintended disconnection, for single use, 4 pieces for securing 4 M12 plug-in connectors	C1000079

14 **EC declaration of conformity**

This product/these products meet the requirements of the directive 2006/42/EC on machinery of the European Parliament and of the Council. The complete EC Declaration of Conformity is available on the Internet at www.pilz.com/downloads.

Representative: Pilz GmbH & Co. KG, Felix-Wankel-Str. 2, 73760 Ostfildern, Germany

15 UKCA-Declaration of Conformity

This product(s) complies with following UK legislation: Supply of Machinery (Safety) Regulation 2008.

The complete UKCA Declaration of Conformity is available on the Internet at www.pilz.com/downloads.

Representative: Pilz Automation Technology, Pilz House, Little Colliers Field, Corby, Northamptonshire, NN18 8TJ United Kingdom, eMail: mail@pilz.co.uk

Support

Technical support is available from Pilz round the clock.

Americas

Brazil

+55 11 97569-2804

Canada

+1 888 315 7459

Mexico

+52 55 5572 1300

USA (toll-free)

+1 877-PILZUSA (745-9872)

Asia

China

+86 400-088-3566

Japan

+81 45 471-2281

South Korea

+82 31 778 3300

Australia and Oceania

Australia

+61 3 95600621

New Zealand

+64 9 6345350

Europe

Austria

+43 1 7986263-444

Belgium, Luxembourg

+32 9 3217570

France

+33 3 88104003

Germany

+49 711 3409-444

Ireland

+353 21 4804983

Italy, Malta

+39 0362 1826711

Scandinavia

+45 74436332

Spain

+34 938497433

Switzerland

+41 62 88979-32

The Netherlands

+31 347 320477

Türkiye

+90 216 5775552

United Kingdom

+44 1536 462203

**You can reach our
international hotline on:**

+49 711 3409-222

support@pilz.com

Pilz develops environmentally-friendly products using ecological materials and energy-saving technologies. Offices and production facilities are ecologically designed, environmentally-aware and energy-saving. So Pilz offers sustainability, plus the security of using energy-efficient products and environmentally-friendly solutions.



CECE®, CHRE®, CMSE®, INDUSTRIAL P®, Leansafe®, Myzel®, PAS4000®, PAScal®, PASconfig®, Pilz®, PIT®, PMCPirotego®, PMCPirotego®, PMD®, PME®, PNOZ®, Primo®, PSEN®, PSS®, PSS®, PVIS®, SafetyBUS p®, SafetyNET p®, THE SPIRIT OF SAFETY® are registered and protected trademarks of Pilz GmbH & Co. KG in some countries. We would point out that product features may vary from the details stated in this document, depending on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirety of the text and graphics presented in this information. Please contact our Technical Support if you have any questions.

We are represented internationally. Please refer to our homepage www.pilz.com for further details or contact our headquarters.

Headquarters: Pilz GmbH & Co. KG, Felix-Wankel-Straße 2, 73760 Ostfildern, Germany
Telephone: +49 711 3409-0, E-Mail: info@pilz.com, Internet: www.pilz.com

PILZ
THE SPIRIT OF SAFETY